


CAUTION:


To clean use soft, dry cloth. Do not use detergent or chemicals
 Avoid contact with water and direct sunlight.
 To be assembled on a soft, dry, clean and smooth surface.



COMPLETE SET

ORDERING REPAIR PARTS

In order to obtain smooth and rapid service when ordering repair parts, please give full attention to the following of PART NUMBER.



NO	DESCRIPTION	QTY
A	LEFT SIDE	01
B	LOWER SHELF	01
C	LEG	01
D	CENTRE SHELF	01
E	HORIZONTAL SHELF	01
F	TOP	01
G	RIGHT SIDE	01


NO	DESCRIPTION	QTY
H	BACK	02
I	LEFT SIDE DOOR	01
J	RIGHT SIDE DOOR	01
K	MOVABLE SHELF	03
L	DRAWER FACE	01

ASSEMBLY INSTRUCTION


MODEL : 7048 / SHOE RACK

Before you begin, please follow assembly instruction carefully. Then follow them step by step.


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5



STEP 6



HARDWARE LIST			
NO	DESCRIPTION		QTY
I	JCBCW SCREW M6 x 45		12pcs
II	M4 ALLEN KEY		1pc
III	HANDLE & SCREW M3.5 x 30		3sets
IV	HINGE (A) & SCREW M3.5 x 16		4sets
V	M8 x 30 PLASTIC DOWEL		4pcs

VI	Q-FIT		8sets
VII	NAIL		50pcs
VIII	PVC NAIL WITH PIN		5pcs
IX	CAP SMALL		12pcs
X	SHELF SUPPORT		12pcs
XI	M8 x 32 CHIPBOARD SCREW		4pcs
XII	DRAWER SLIDER & SCREW M3.5 x 12		1sets

[illegible]