


CAUTION:


To clean use soft, dry cloth. Do not use detergent or chemicals
 Avoid contact with water and direct sunlight.
 To be assembled on a soft, dry, clean and smooth surface.



COMPLETE SET

ORDERING REPAIR PARTS

In order to obtain smooth and rapid service when ordering repair parts, please give full attention to the following of PART NUMBER.



NO	DESCRIPTION	QTY
A	LEFT SIDE	01
B	LOWER SHELF	01
C	CENTRE SHELF	01
D	UPPER SHELF	01
E	LEG	01
F	RIGHT SIDE	01


NO	DESCRIPTION	QTY
G	TOP	01
H	BACK	02
I	LEFT SIDE DOOR	01
J	RIGHT SIDE DOOR	01
K	MOVABLE SHELF	05

ASSEMBLY INSTRUCTION


MODEL : 7050 / SHOE RACK

Before you begin, please follow assembly instruction carefully.
Then follow them step by step.


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5



STEP 6



HARDWARE LIST

NO	DESCRIPTION		QTY
I	JCBCW SCREW M6 x 45		14pcs
II	M4 ALLEN KEY		1pc
III	CAP SMALL		12pcs

IV	HANDLE & SCREW M3.5 x 30		2sets
V	M8 x 30 PLASTIC DOWEL		4pcs
VI	HINGES & SCREW M3.5 x 16		6sets
VII	NAIL		50pcs
VIII	PVC NAIL WITH PIN		4pcs

IX	PVC SHELF SUPPORT		20pcs
X	M3.5 x 30 CHIPBOARD SCREW		1pc