



CAUTION:

To clean use soft, dry cloth. Do not use detergent or chemicals
Avoid contact with water and direct sunlight.
To be assembled on a soft, dry, clean and smooth surface.

ORDERING REPAIR PARTS

In order to obtain smooth and rapid service when ordering repair parts,
please give full attention to the following of PART NUMBER.



COMPLETE SET


NO	DESCRIPTION	QTY
A	LEFT SIDE	01
B	LOWER SHELF	01
C	CENTRE SHELF	01
D	LEG	01
E	RIGHT SIDE	01
F	TOP	01

NO	DESCRIPTION	QTY
G	LEFT SIDE WRAPPING	01
H	FRONT WRAPPING	01
I	RIGHT SIDE WRAPPING	01
J	BACK	01
K	DOOR	01


ASSEMBLY INSTRUCTION
MODEL : 5081 / SIDE TABLE

Before you begin, please follow assembly instruction carefully.
 Then follow them step by step.


STEP 1




STEP 2



STEP 3



STEP 4



HARDWARE LIST			
NO	DESCRIPTION		QTY
I	JCBCW SCREW M6 x 45		8pcs
II	M4 ALLEN KEY		1pc
III	HANDLE & SCREW M4 x 22		1sets

IV	PLASTIC DOWEL		4pcs
V	Q-FIT		4sets
VI	PVC NAIL WITH PIN		4pcs
VII	CAP SMALL		4pcs
VIII	M4 x 25 CHIPBOARD SCREW		12pcs

IX	NAIL		20pcs
X	HINGE (C) & SCREW M3.5 x 16		2sets