








197-000182



Instruction Manual





A01 14x *14 mm	A02 14x *5x45 mm	A03 16x *8x30 mm	A04 14x
A10 14x *3.5x18 mm	A13 8x 	A14 4x 	A15 8x
A16 4x 	A17 3x *3.5x50 mm	A18 32x *4x20 mm	A19 4x
A20 4x 	A21 4x 	A22 4x 	A23 8x





Important information
Read carefully.
Keep this information for further reference.

GB WARNING


Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.


14.





1.






2.





3.




4.




13.





11.






12.




5.




6.






7.



8.



9.



10.

