


















197-000203



Instruction Manual





A01 8x  *14 mm	A02 8x  *5x45 mm	A03 8x  *8x30 mm	A04 8x 
A10 24x  *4x20 mm	A13 2x 	A14 2x 	A15 4x 
A16 4x 	A17 1x 		




Important information
 Read carefully.
 Keep this information for further reference.

GB WARNING


Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.

7.




8.




Depending on your usage direction, you can mount the door in the direction you prefer.

9.





Depending on your usage direction, you can mount the door in the direction you prefer.




10.




1.




2.



3.



4.




A01


A01

A02

A03



5.



A01


A01

A02

A03



6.



A16